

AERO Speed Wax



Application:

In the case of coarse soiling, clean the surfaces to be treated thoroughly first, e.g. with **AERO Aircraft Cleaner**, and then rub dry.

Shake the **AERO Speed Wax** well before use.

Apply thinly and evenly onto the painted surfaces.

Only treat partial areas.

After a short flash-off time (2-3 minutes), polish the surfaces to be treated with a dry, soft rag, e.g. with **AERO Cockpit Cleaning Rag**.

Important:

Cellulose or paper towels are not suitable for polishing out or re-polishing.

Do not spray on strongly heated surfaces and do not use in direct sunlight. Do not use on polycarbonate plastics and acrylic glass.