

AERO Rubber Seal Care



Application:

For small areas to be sprayed:
Spray product on a rag and gently treat parts.

For large surfaces:
Spray product directly onto the parts to be handled, leave to act for 2-3 minutes, and rub with a soft rag.

Do not spray on tire treads.

Regular treatment results in optimal appearance of rubber surfaces in addition to material protection.